

Sky-Kote 45Acrylic Skylight Coating

CLEAR COATING FOR FIBERGLASS SKYLIGHT RESTORATIONS



BEFORE

AFTER

SURFACE PREPARATION:

Skylight must be clean, dry & free of oil, grease or dirt. Existing coating must be checked for proper adhesion. Any loosely adhered coating must be removed and surfaces must be properly cleaned and checked for compatibility.

APPLICATION:

Mix lightly prior to application. Apply to surfaces by roof brush, medium nap roller or airless spray equipment.

COVERAGE RATE:

Apply two coats of #45 Sky-Kote to the skylight surface at the rate of 1.5 gallons per 100 sq. ft. per coat. Depending on the irregularity of the surface additional coats may be required to achieve a smooth surface.



POWER-WASHING WITH 799 WASH-N-PREP

KARNAK Corporation | 800-526-4236 | www.karnakcorp.com Manufacturing Facilities: Clark, NJ | Kingman, AZ | Broadview, IL | Ft. Lauderdale, FL Warehouses: Dallas, TX | Rancho Cucamonga, CA | Renton, WA

Key benefits...

- Dries quickly to a water clear film.
- Seals scratches and small cracks.
- Hvdrophobic water beading film.
- Renews light transmission.
- Reduces dirt build up on surface.
- Easy application

Keys to Success...

- Power-wash using #799 Wash-N-Prep
- Replace all fasteners
- 3-course skilight to roof transition with Karna-Flex WB & 6" Resat-Mat
- Incorporate maintenance program