

## APPLICATION GUIDELINES

WHITE REFLECTIVE COATING SYSTEM

**Substrates:** 

Metal - Kynar® Finish

Mastic Type: Karna-Flex WB

**Base Coat:** 

**404 Corrosion Proof**Base Coat

Finish Coat: 501 Elasto-Brite White The following KARNAK Roof Restoration System is intended to be applied over sound metal roofing systems with a weathered Kynar® coated metal finish.

#### **BENEFITS & ADVANTAGES:**

- Elastomeric coating system designed to seal and protect metal roofing systems.
- Incorporates the use of a primer specifically designed for adhering to Kynar® finish metal roofs that have weathered at least four years.
- Substrate specific base coat has excellent adhesion direct to metal and primed metal surfaces.
- Application causes no disruption of activities inside building.
- Encapsulates surface rust on properly prepared metal surfaces and inhibits the formation of new rust.
- Energy Star® listed reflective coating reduces energy consumption by lowering air conditioning requirements.
- Can provide an energy savings "payback" based on building design, energy consumption needs and insulation levels.
- Sustainable Avoids roof replacement and adds life to the existing roof system.

## **PART 1 - MATERIALS**

- 1.1 **799 Wash-N-Prep:** Concentrated liquid TSP substitute specifically designed to clean roof surfaces prior to applying coatings.
- 1.2 **702 K-Prep:** An acrylic elastomeric primer specifically designed to improve adhesion to weathered Kynar® coated metal roofing.
- 1.3 **Karna-Flex WB:** An acrylic elastomeric mastic for sealing and repairing flashings, curbs, fasteners, penetrations and general repairs to all types of asphalt roofs prior to applying acrylic coatings.
- 1.4 **5540 Resat-Mat:** Spunlaced polyester fabric for reinforcing mastics and coatings over irregular, rough surfaces as well as smooth surfaces.
- 1.5 **404 Corrosion Proof Base Coat:** Self-priming, modified acrylic base coat designed to go over sound and properly prepared rusted and non-rusted metal surfaces to prevent the development of new rust.
- 1.6 **501 Elasto-Brite White:** A highly reflective, elastomeric roof coating exhibiting outstanding color stability, flexibility, mildew resistance and weatherability.

**Substrates:** 

Metal - Kynar® Finish

Mastic Type: Karna-Flex WB

**Base Coat:** 

**404 Corrosion Proof**Base Coat

Finish Coat: 501 Elasto-Brite White

#### **PART 2 - APPLICATION:**

#### 2.1 General:

- A. Read all applicable product data sheets and SDS for appropriate application and preparation guidelines.
- B. All roof surfaces to be coated should be sound, clean, dry and free of dirt, loose coating, heavy flaking or pitting rust, grease, oil, foreign contaminants and debris.
- C. All fasteners should be re-tightened or replaced as necessary. Stripped fasteners must be replaced with larger fasteners. All fasteners should include a neoprene washer.
- D. Rusted through panels or sections must be replaced.
- E. Rusted areas should be wired brushed down to clean, stable metal.
- F. Damaged skylights, if applicable, should be removed and replaced.
- G. Remove all non-functioning vents, penetrations, antenna and non-working equipment.
- H. Adhesion of the coatings should be tested over all applicable roof surfaces prior to the system application.

# 2.2 **Preparation:**

- A. Cut away low handing branches and vegetation that extend onto the roof.
- B. Remove all loose coating and repairs. Silicone caulking must be removed prior to coating system application.
- C. Power-wash all surfaces to be coated with 799 Wash-N-Prep Roof Cleaner and water maintaining a minimum of 3,000 psi. Take all necessary precautions to avoid damage to the roof system when power washing.
  - a. Dilute 799 Wash-N-Prep with water at a 16:1 ratio for normal cleaning.
  - Apply diluted cleaning agent directly to the roof surface with a Hudson-type sprayer or using a stiff nylon brush by dipping the brush into a bucket of diluted cleaner.
     Cleaner may also be added in full strength to the detergent reservoir for injection dilution at a 16:1 ratio.
  - Rinse all surfaces thoroughly with a heavy duty power washer using clean water to completely remove all residues. Do not allow dirty solution to pool on the roof and dry.
  - d. Allow the roof to completely dry before applying KARNAK coating products.

## **Substrates:**

Metal - Kynar® Finish

Mastic Type: Karna-Flex WB

#### **Base Coat:**

404 Corrosion Proof Base Coat

**Finish Coat:** 

501 Elasto-Brite White

## 2.3 **Primer Application:**

- A. All metal roof surfaces to be sealed and coated must first be primed with 702 K-Prep. Weathered Kynar® metal should be at least four years old.
- B. Application of the 702 K-Prep should take place when temperatures are 45°F-100°F and humidity levels are 85% or less.
- C. Thoroughly mix the 702 K-Prep to overcome any settling that may occur.
- D. Apply one coat of 702 K-Prep over the entire metal roof at the rate of 0.5 gallons per 100 sq.ft.
- E. Apply with airless spray equipment, medium nap roller or soft roofing brush.
- F. Allow the coating to dry 2-4 hours before applying subsequent sealants or coatings.

## 2.4 Seam Sealing - Horizontal Seams & Penetrations:

- A. All horizontal seams, penetrations and cracks should be sealed using 6" wide 5540 Resat-Mat and Karna-Flex WB.
  - a. Apply Karna-Flex WB over the seam in a 1/16" thickness by 8" width using a 3" or 4" 'chip type' brush.
  - b. While still wet, immediately embed 6" wide Resat-Mat into the wet Karna-Flex WB. Brush Resat-Mat to smooth out and removed any wrinkles or fishmouths.
  - c. Apply a second and final application of Karna-Flex WB over the embedded Resat-Mat. Apply at an average thickness of 1/16" by 8" wide to completely cover the Resat-Mat, feathering out the Karna-Flex WB on to the roof surface. No fabric should be visible.
  - d. Total coverage of Karna-Flex WB in this application is approximately 20 lineal feet per gallon.
  - e. Allow all repairs to cure 24-48 hours before applying subsequent coating.

### 2.5 **Seam Sealing - Vertical Seams:**

- A. For vertical seams less than 1/16" wide brush apply a 2" wide 'bead' by 1/16" thick application of Karna-Flex WB along the seam, back brushing the coating into the seam.
- B. Total coverage of Karna-Flex WB in this application is approximately 160 lineal feet per gallon
- C. For vertical seams open greater than 1/16" wide treat in the same manner as a Horizontal Seam and three-course with Karna-Flex WB and 5540 Resat-Mat as described above.
- D. Allow all repairs to cure 24-48 hours before applying subsequent coating.

#### **Substrates:**

Metal – Kynar® Finish

Mastic Type: Karna-Flex WB

## **Base Coat:**

**404 Corrosion Proof**Base Coat

Finish Coat: 501 Elasto-Brite White

## 2.6 Fastener Sealing:

- A. All fasteners must receive a dollop (swirl coat) of Karna-Flex WB using a 1" or 2" chip brush to completely encapsulate the fastener. Allow Karna-Flex WB to completely cure before applying base coat.
- B. Applicator should "swirl" apply the Karna-Flex WB around the faster to ensure there is no trapped air between the Karna-Flex WB and the fastener.
- C. 1 gallon of Karna-Flex WB covers approximately 250 fasteners in this application.
- D. Allow all repairs to cure 24-48 hours before applying subsequent coating.

## 2.7 Base Coat Application:

- A. Application of the 404 Corrosion Proof Base Coat should take place when temperatures are 45°F-100°F and humidity levels are 85% or less.
- B. 404 Corrosion Proof Base Coat is a self-priming, fully elastomeric base coat formulated specifically for metal roof surfaces and is light gray in color to allow for easy application of the white finish coat.
- C. Thoroughly mix the 404 Corrosion Proof Base Coat to overcome any settling that may occur prior to application of coating.
- D. Apply one coat of 404 Corrosion Proof Base Coat over the entire metal roof and previously applied Karna-Flex WB at the rate of 1.5 gallons per 100 sq.ft. (24 wet mils).
- E. Apply with heavy-duty airless spray equipment, medium nap roller or soft roof brush.
- F. Allow base coat to dry 12-24 hours before applying subsequent coatings.

### 2.8 Finish Coat Application:

- A. Application of the 501 Elasto-Brite White should take place when temperatures are 40°F-100°F and humidity levels are 85% or less.
- B. Thoroughly mix the 501 Elasto-Brite White to overcome any settling that may occur.
- C. Apply one coat of 501 Elasto-Brite White over the entire metal roof previously coated with 404 Corrosion Proof Base Coat at the rate of 1.5 gallons per 100 sq.ft. (24 wet mils).
- D. Apply with heavy-duty airless spray equipment, medium nap roller or soft roofing brush.
- E. Allow the coating to dry 24 hours before making any touchups.

**Substrates:** 

Metal – Kynar® Finish

Mastic Type: Karna-Flex WB

**Base Coat:** 

404 Corrosion Proof Base Coat

Finish Coat: 501 Elasto-Brite White

## 2.9 Material List & Coverage Rates:

Note: The below listed coverage rates are for estimating purposes only. Actual amounts may vary depending upon the irregularity and porosity of the roof surface, measurements taken and applicator installation.

A. **799 Wash-N-Prep:** 1 quart per 1,600 sq.ft. B. **702 K-Prep:** 0.5 gal. per 100 sq.ft.

C. Karna-Flex WB:

With Resat-Mat 20 lineal feet per gallon Without Resat-Mat 160 lineal feet per gallon

D. 5540 Resat-Mat: 6" x 300' per roll
E. 404 Corrosion Proof Base Coat: 1.5 gal. per 100 sq.ft.
F. 501 Elasto-Brite White: 1.5 gal. per 100 sq.ft.

This specification is based upon information and/or pictures provided to us by the applicator/contractor. KARNAK has not inspected the roof or independently verified any of the information provided. KARNAK is relying solely on the applicator/contractor to determine that the roof structure and condition of the roof makes the roof an appropriate candidate for coating, and that a moisture test or other procedure has been performed to verify that the substrate is not wet. The recommended use of KARNAK products listed are predicated on tests believed to be reliable. However, since such application and use is beyond our control, we do not guarantee the results to be obtained. The above specification is offered as a service to the specifier. KARNAK Corporation does not practice architecture nor engineering and recommends that you consult a registered architect, engineer and/or roofing consultant. Accordingly KARNAK disclaims all liability in connection with the use of this specification.

### KARNAK CORPORATION

330 Central Avenue Clark, NJ 07066 • 800.526.4236 • Fax 732.388.9422 www.karnakcorp.com

Manufacturing: Ft. Lauderdale, FL • Chicago, IL • Kingman, AZ Warehouses: Dallas, TX • Rancho Cucamonga, CA • Tukwila, WA